

**Архангельск** (8182)63-90-72  
**Астана** (7172)727-132  
**Астрахань** (8512)99-46-04  
**Барнаул** (3852)73-04-60  
**Белгород** (4722)40-23-64  
**Брянск** (4832)59-03-52  
**Владивосток** (423)249-28-31  
**Волгоград** (842)78-03-48  
**Вологда** (8172)26-41-59  
**Воронеж** (473)204-51-73  
**Екатеринбург** (343)384-55-89  
**Иваново** (4932)77-34-06  
**Ижевск** (3412)26-03-58  
**Иркутск** (395)279-98-46  
**Казань** (843)206-01-48  
**Калининград** (4012)72-03-81  
**Калуга** (4842)92-23-67  
**Кеморово** (3842)65-04-62  
**Киров** (8332)68-02-04  
**Краснодар** (861)203-40-90  
**Красноярск** (391)204-63-61  
**Курск** (4712)77-13-04  
**Липецк** (4742)52-20-81  
**Киргизия** (996)312-96-26-47  
**Россия** (495)268-04-70  
**Магнитогорск** (3519)55-03-13  
**Мурманск** (8152)59-64-93  
**Набережные Челны** (8552)20-53-41  
**Нижний Новгород** (831)429-08-12  
**Новосибирск** (383)227-86-73  
**Омск** (3812)21-46-40  
**Орел** (4862)44-53-42  
**Оренбург** (3532)37-68-04  
**Пенза** (8412)22-31-16  
**Казхстан** (772)734-952-31  
**Пермь** (342)205-61-47  
**Ростов-на-Дону** (863)308-18-15  
**Рязань** (4912)46-61-64  
**Самара** (846)206-03-16  
**Санкт-Петербург** (812)309-46-40  
**Саратов** (845)249-38-78  
**Севастополь** (8692)22-31-93  
**Симферополь** (3652)67-13-56  
**Смоленск** (4812)29-41-54  
**Сочи** (862)225-72-31  
**Ставрополь** (8652)20-65-13  
**Сургут** (3462)77-98-35  
**Тверь** (4822)63-31-35  
**Томск** (3822)98-41-53  
**Тула** (4872)74-02-29  
**Тюмень** (3452)66-21-18  
**Ульяновск** (842)24-23-59  
**Уфа** (347)229-48-12  
**Хабаровск** (4212)92-98-04  
**Челябинск** (351)202-03-61  
**Череповец** (8202)49-02-64  
**Ярославль** (4852)69-52-93

<https://hongling.nt-rt.ru/> || [hgo@nt-rt.ru](mailto:hgo@nt-rt.ru)



## Converter Spiral Mixer



BC-20A (8kg Converter inside)



BC-30A (12kg Converter inside)



BC-40A (15kg Converter inside)

BC-50A (20kg Converter inside)

BC-60A (25kg Converter inside)

Model	Product Name	Voltage & Power	Flour Capacity	Net Weight	Dimension(mm)	Hook Speed	Bow Speed	Bowl Capacity
BC-20A	20L Spiral Mixer (8kg, Converter inside)	220V 50Hz 1.5kW	8kg	93kg	700x390x770	125/250rpm	12/25rpm	20L
BC-30A	30L Spiral Mixer (12kg, Converter inside)	220V 50Hz 2.0kW	12kg	117kg	770x440x850	125/250rpm	12/25rpm	30L
BC-40A	40L Spiral Mixer (15kg, Converter inside)	220V 50Hz 2.2kW	15kg	125kg	770x440x850	125/250rpm	12/25rpm	40L
BC-50A	50L Spiral Mixer (20kg, Converter inside)	220V 50Hz 4.0kW	20kg	160kg	880x500x920	125/250rpm	12/25rpm	50L
BC-60A	60L Spiral Mixer (25kg, Converter inside)	220V 50Hz 4.0kW	25kg	177kg	880x530x920	125/250rpm	12/25rpm	60L
BC-20A	20L Spiral Mixer (8kg)	380V 50Hz 1.1kW	8kg	93kg	700x390x770	125/250rpm	12/25rpm	20L
BC-30A	30L Spiral Mixer (12kg)	380V 50Hz 1.5kW	12kg	117kg	770x440x850	125/250rpm	12/25rpm	30L
BC-40A	40L Spiral Mixer (15kg)	380V 50Hz 1.8kW	15kg	125kg	770x440x850	125/250rpm	12/25rpm	40L
BC-50A	40L Spiral Mixer (20kg)	380V 50Hz 3.0kW	20kg	177kg	880x500x920	125/250rpm	12/25rpm	50L
BC-60A	60L Spiral Mixer (25kg)	380V 50Hz 3.0kW	25kg	177kg	880x530x920	125/250rpm	12/25rpm	60L

